1	Before driving		Rear seat position memory
1-1.	Hybrid system		Steering wheel 101
	Hybrid system30		Anti-glare inside rear view mirror
1-2.	Key information		Outside rear view mirrors 104
	Keys 41	1-5.	Opening and closing the windows and moon roof
1-3.	1 3, 3		Power windows106
	the doors and trunk		
	Smart access system with		Moon roof 109
	push-button start	1-6.	Refueling
			Opening the fuel tank cap 112
	Doors		Opening the Identaria cap
	1runk 07	1-7.	Theft deterrent system
1-4.	Adjustable components		Immobilizer system 117
	(seats, mirrors,		Alarm119
	steering wheel) Front seats74		Theft prevention labels (U.S.A.)121
	Power rear seat (5-seat models)	1-8.	Safety information
	Power rear seat		Correct driving posture 122
	(4-seat models) 80		SRS airbags 124
	Driving position memory		Front passenger occupant
	Seat position memory		classification system
			Child restraint systems 143
			Installing child restraints 148

Electronically modulated

air suspension......226

		Rear view monitor system 228
2-1.	Driving procedures	Driving assist systems
	Driving the vehicle	Pre-Collision System
2-2.	Transmission 175 Turn signal lever 179 Parking brake 180 Brake Hold 182 Horn 184 Instrument cluster	2-5. Driving information Cargo and luggage
	Gauges and meters	3 Interior features
2-3.	Operating the lights and windshield wipers Headlight switch	3-1. Using the touch screen Touch screen
	Fog light switch	3-2. Using the air conditioning system and defogger Front air conditioning system (without rear air conditioning system)
2-4.	Using other driving systems Cruise control	Front air conditioning system (with rear air conditioning system)
	Intuitive parking assist	system290

When driving

	Rear window and outside rear view mirror defoggers 298 Windshield wiper de-icer	Using the front DVD player 368 Using the rear DVD player 369 Playing an audio CD/CD text
3-3.	Using the audio system Audio system	Playing WMA (front DVD player only)/MP3 discs
3-4.	Using the rear seat entertainment system Rear seat entertainment system features	3-6. Using the interior lights Interior lights list

3-7.	Using the storage features		M
	List of storage features		Maintenance and care Maintenance and care Cleaning and protecting the vehicle exterior
3-8.	Other interior features	4-2.	Maintenance
	Sun visors		Maintenance requirements 514
	Vanity mirrors		General maintenance 516
	Clock459 Outside temperature		Emission inspection and maintenance (I/M)
	display 461		programs519
	Ashtrays 462		
	Cigarette lighters463	4-3.	Do-it-yourself maintenance
	Power outlets 465		Do-it-yourself service
	Heated steering wheel 467		precautions 520
	Climate control seats/		Hood
	seat heaters469		Positioning a floor jack 524
	Armrest 473		Engine compartment 526
	Rear seat relaxation system 474		12-volt battery 538
	Retractable table 476		Tires 542
	Rear sunshade 478		Tire inflation pressure 550
	Rear door sunshades 481		Wheels 554
	Coat hooks 484		Air conditioning filter556
	Floor mat		Electronic key battery 559
	Trunk features		Checking and replacing fuses
	Garage door opener		Headlight aim 581
	Lexus Link System 495		Light bulbs 584

	vehicle interior	511
-2.	Maintenance	
	Maintenance requirement	s 514
	General maintenance	516
	Emission inspection and maintenance (I/M)	
	programs	519
-3.	Do-it-yourself maintenan	ce
	Do-it-yourself service precautions	520
	Hood	523
	Positioning a floor jack	524
	Engine compartment	526
	12-volt battery	538
	Tires	542
	Tire inflation pressure	550
	Wheels	554
	Air conditioning filter	556
	Electronic key battery	559
	Checking and replacing fuses	561
	Headlight aim	581

If the hybrid system will

If the shift lever cannot be

If the parking brake cannot

If the electronic key does

If the vehicle 12-volt battery

If the vehicle becomes

shifted from "P"...... 630

not operate properly 634

When trouble arises Vehicle specifications 5-1 Essential information 6-1. Specifications Emergency flashers...... 598 Maintenance data If your vehicle needs to be towed...... 599 Fuel information...... 658 If you think something is 6-2. Customization 5-2. Steps to take in an emergency If a warning light turns on 6-3. Initialization or a warning buzzer If a warning message is displayed...... 617 For owners If you have a flat tire...... 620

##